DMX CHANNEL 8-BIT (DEFAULT)	DMX CHANNEL 16-BIT	PARAMETER	DEFAULT	RANGE	DESCRIPTION
1	1	Intensity (16-Bit High)	0	0 - 255	intensity (Dimmer) control channel
	2	Intensity (16-Bit Low)		0 - 65535 (16Bit)	
2	3	Strobe	0	0	Open
				1 -255	Strobe speed Slow>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>>