

-  12.0 Kg/m
-  ((RFID) READY)
-  L
-  P.100
-  ALU/BLACK

Square - L35S

Code	Length
151001	50 cm
151002	60 cm
151003	80 cm
151004	100 cm
151005	120 cm
151006	150 cm
151007	200 cm
151008	240 cm
151009	250 cm
151010	300 cm
151012	400 cm

Load table L35S


Span m	CPL kg	Deflection mm	2 x load kg	Deflection mm	3 x load kg	Deflection mm	4 x load kg	Deflection mm	UDL kg/m	Deflection mm
2.0	2948.2	3	1865.9	4	1412.9	3	1146.1	4	2303.8	4
4.0	1873.0	12	1216.4	15	995.6	14	822.1	15	1146.5	15
6.0	1380.8	26	929.4	34	778.9	31	597.4	34	595.5	33
8.0	1085.3	47	747.2	60	595.8	56	465.6	60	330.3	58
10.0	886.2	73	620.1	93	477.9	87	378.1	93	207.5	91
12.0	741.7	105	525.7	134	394.9	125	315.3	134	140.8	132
14.0	630.9	143	452.0	183	332.7	170	267.5	183	100.6	179
16.0	542.6	187	392.6	239	284.0	222	229.7	239	74.5	234
20.0	408.3	292	300.8	373	211.2	347	172.6	373	43.8	365

Cantilever load

Span m	1 x Load kg	Deflection mm	UDL kg/m	Deflection mm
0.5	2120.6	0	4618.3	0
1.0	1470.3	1	2114.9	1
1.5	1131.1	3	1163.5	2
2.0	931.9	8	730.8	5
2.5	790.6	17	501.9	8
3.0	684.8	30	372.6	13
3.5	602.4	49	287.3	18
4.0	536.4	75	228.0	25

Multiple supported span

Span m	CPL kg	Deflection mm	2 x Load kg	Deflection mm	UDL kg/m	Deflection mm
2.0	2971.0	1	1586.3	1	1828.5	1
4.0	2005.9	4	1097.8	3	670.1	3
6.0	1537.5	10	837.4	9	340.7	8
8.0	1246.2	19	682.7	17	211.6	15
10.0	1038.2	31	571.1	28	143.2	25
12.0	880.9	46	486.0	41	102.5	37
14.0	756.6	62	418.5	56	76.2	51
16.0	655.2	80	363.1	73	58.2	66
20.0	497.3	119	276.5	108	35.7	112

 Find complete loading tables on SIXTY82.nl

All loading data is based on calculations per EN-1999-1-1 and the following assumptions:

- Static loads only.
- Spans supported or suspended at both ends.
- Triangle trusses solely used apex-up, apex-down.
- 2 chords truss to be placed upright, supported from top chord and loaded from bottom chord.
- Truss spans can be constructed of elements of different length.
- Interaction between bending moment and shear force considered.
- Self-weight of truss is already considered.
- Assembled truss systems need an individual structural calculation. Please contact SIXTY82 or a structural engineer.
- Read the manual before use.
- Higher loading can be allowed depending on the truss configuration.