


Quick Start

MDG Me8

Installation

- Connect the gas inlet to a gas bottle equipped with a regulator. The gas inlet is an Oxygen Adaptor (9/16-18 R.H).
- Connect the data wiring (Male XLR-5 connector for DMX/RDM) if you are using a DMX or RDM controller.
- Connect the power cord 190-250 VAC, 50/60 Hz, 5630W.
- Open the gas bottle (CO₂ or N₂ industrial grade, over 99% of purity), and set the regulator pressure between 50 and 60 psi (3.5 and 4.1 bar, or 350 and 410 kPa).
- Fill the reservoir with MDG Neutral Fog Fluid.

Power ON the MDG Me8.



Working with the keyboard (LOCAL Mode)

- Verify the communication mode in the «INTERFACE ▶ COMM. ». When the «AUTO» mode is activated, the MDG **Me8** is then controlled by DMX, only if there is a signal. If the DMX wire is unplugged, the control remains local.
- When the generator is manually switched to **«UNIT ON»** mode (**«**CONTROL **▶** UNIT **▶** ON**»**), the program starts the heating cycle for approximately 8 minutes (**«**STATUS **▶** STATE = % HEAT**»**).
 - When the temperature reaches operating level, the Automatic Purging SystemTM (APSTM) will be initiated (\ll STATUS \blacktriangleright STATE = PURGE»).
 - After the first purging cycle is completed (1 min), the generator is ready to produce fog («STATUS ▶ STATE = READY»).
- To produce Fog, switch the generator to **«FOG ON»** mode (**«**CONTROL **▶** FOG **▶** ON»).
 - The MDG **Me8** will start to produce fog right away.
 - Fog emission can be controlled by adjusting the working pressure of the internal reservoir («CONTROL ▶ PRESSURE»).

The MDG **Me8** will produce fog as long as the control parameters are within specifications, the fog fluid reservoir filled and the gas bottle pressurized.

If a critical problem occurs, the fog generator <u>automatically shuts down</u>, and displays an error message in the **Status Menu**. The most common errors are (check the manual for more details):

• ERROR = P. LOW Gas bottle is probably closed, empty or not connected. Check also the regulator pressure.

• ERROR = P. HIGH The input gas pressure is too high (Pressure between 50-60 psi / 3.5-4.1 bar / 350-410 kPa).

• ERROR = HEATER Check the AC voltage.

• ERROR = PCB HIGH Move the generator to a colder location.

Working with DMX/RDM Control (DMX Mode)

- Connect a DMX line to DMX In connector (Male XLR-5 connector).
- Select the communication mode in the «INTERFACE → COMM. ». When the «AUTO» mode is activated, the MDG **Me8** is then controlled by DMX, only if there is a DMX signal.
- Set the DMX Start Address in the Interface Menu («INTERFACE ▶ COMM. ▶ DMX ADDR»), and choose any value between 1 and 510 (512, last DMX channel).

The DMX Start Address can be reassigned via a RDM control.


The generator uses three (3) DMX channels:

•	Channel 1	0 (0%)	< UNIT OFF	≤ 128 (50%)	< UNIT ON	≤ 255 (100%)
•	Channel 2	0 (0%) – 255	(100%), FOG O	UTPUT (from minim	um to maximum)	

• Channel 3 0 (0%) < FOG OFF $\leq 128 (50\%)$ < FOG ON $\leq 255 (100\%)$

Technical Specifications

Maximum fog output (per minute):	800 m³ (28,250 ft³)			
Fog colour:	Pure white			
Particle size:	0.5 to 0.7 microns			
Fluid consumption:	8 L (238 oz / 2.12 US gal) per hour at 2.76 bar / 40 psi			
Fluid type:	MDG Neutral[™] Fog Fluid ONLY			
	M.S.D.S. available on request			
Fluid reservoir:	9.5 L (2.5 US gal) bottle			
Gas type:	Industrial Grade CO ₂ or N ₂			
Gas pressure input:	4.15 bar / 60 psi max			
Gas consumption:	6.8 kg (15 lb) per hour at 2.76 bar / 40 psi			
Operating voltage:	190-250 VAC, 50/60Hz, 1 phase, 5630 W			
	Ground / Earth connection REQUIRED			
Operating temperature:	0 °C to 50 °C (32 °F to 122 °F)			
Operating humidity:	90 % relative humidity @ 50 °C (122 °F), non-condensing			
Storage temperature:	-40 °C (-40 °F) to 60 °C (140 °F)			
Storage humidity:	80% relative humidity @ 60° C (140 °F)			
Approval	CE, CSA and UL pending			
Dimensions	41.5 cm (16.3") H x 30.5 cm (12.0") W x 73. cm (28.7") L			
Weight:	45 kg (100 lb)			



... For further details, please read the **User Guide.**